


RSV-Z2850U

Thank you for purchasing a Rosewill Server Chassis.
Please read the instruction manual before use and retain for future reference.

INTRODUCTION

RSV-Z2850U is a 2U rackmount industrial chassis for various kinds of server computers which supports ATX (12" x 9.6") form factor motherboard design and PS2 power supply.

PRODUCT OVERVIEW




FEATURES


- Carries 4x internal 3.5" HDD and 2x internal 2.5" SSD, or a total of 6x 3.5" HDD.
- Best cooling design carries up to 4x 80mm cooling fans in the front, 2 pre-installed in the chassis.
- Special design of fixing PCI card in the system (7 pieces max).
- 2x USB 3.0 connectors in front panel.

INSTALLATION GUIDE


Top Cover Disassembly




1. Remove the screws from each side of the Chassis (two on each side). Once the screws are removed, push the top cover to remove from the chassis.




2. Remove HDD cages.




3. Install the Motherboard.




4. Install the Power Supply.




5. 4x 3.5" HDD and 2x 2.5" SSD (or total 6 x 3.5" HDD) can be installed on the HDD cages.



6. Remove brackets and install the Graphics Card.






7. Install HDD cages and GPU Holder.



8. Assemble the Top Cover.

SPECIFICATIONS

Chassis Type	Rackmount
Color	Sliver
Case Material	Metal/Steel, 1.0 mm thickness
Motherboard Compatibility	ATX (12" x 9.6"), Micro-ATX (9.6" x 9.6")
MB Form Factor	2U
Power Supply	PS2/2U Power
Cooling System	
80mm Fans	4 (2 pre-installed)
Expansion	
Internal 2.5" Drive Bays	2
Internal 3.5" Drive Bays	Max 6
Expansion Slots	7
Physical Specifications	
Control & Indicator	1 x Power Switch + 1 x Reset Switch 1 x LED (Power) + 1 x LED (HDD) + 1 x LED (LAN) 2 x USB 3.0
Dimensions(L x W x H)	21.7 x 16.9 x 3.5 in (550 x 430 x 89 mm) 22.6 x 16.9 x 3.5 in (575 x 430 x 89 mm, including Handle & Rackmount Brackets)
Weight	Net Weight: 17.6 lbs; Gross Weight: 21.3 lbs
Package Contents	RSV-Z2850U Server Case, Screws, Other Accessories

PIC	ITEM	PURPOSE
	Screws x 42	Power / 3.5" HDD / Motherboard
	Screws x 8	2.5" HDD
	Standoff x 12	Motherboard



Technical Support Information techsupport@rosewill.com 1-800-575-9885

Please register your product at www.rosewill.com for complete warranty information and support for your product.

RSV-Z2850U_A