



PRODUCT OVERVIEW


Product Diagram



Dimensions (W x H x D): 437.5 x 176.5 x 650 mm (17.22" x 6.95" x 25.59")



Accessory Kit




INSTALLATION GUIDE

Please remove all packaging materials before proceeding to disassembly/assembly.


1. Remove the Top Panel

Loosen the two screws on the side of the panel, press the one-piece push-button switch, and then remove the top panel.






2. Install the Motherboard




3. Install the Power Supply




4. Install the GPU Card

Remove the fans from the back panel, and then install the GPU card.




5. Increase Space

To create extra assembly space, remove the fan bracket and the preinstalled hot-swap 12038 fans.



6. Reinstall the Top Panel


Reinstall the top panel and then secure the fans to the back panel with screws.



7. Insert HDD Tray

Secure the HDD to the HDD tray, and then insert it into the front hot-swap bay.





SPECIFICATIONS

Model	
Model Name	RSV-AI01
Specifications	
Chassis Type	Rackmount
Form Factor	4U
Color	Black & Silver
Case Material	SGCC, 1.0mm
Motherboard Compatibility	12" x 13" E-ATX; 12" x 9.6" ATX; 11.2" x 8.2" Mini-ATX
Power Supply	Supports ATX power supply
Hot-Swap Drive Bays	8 (SFF8643 with SGPIO and Temperature Control)
Internal 2.5" Drive Bays	4
Expansion Slots	11
Front Ports	2 x USB 3.0 / 1 x USB 3.2 Type C
80mm Fans	2 x 8038 Fan
120mm Fans	3 x 12038 Hot-swap PWM Fan
Dimension	437.5 x 650 x 176.5 mm / 17.22" x 25.59" x 6.95"



