



PRODUCT OVERVIEW


Product Diagram



Dimensions (W x H x D): 550 x 430 x 89 mm (21.65" x 16.93" x 3.50")



Accessory Kit




INSTALLATION GUIDE

Please remove all packaging materials before proceeding to disassembly/assembly.

1. Remove the Top Panel



Loosen the two screws on the side panel, then press and hold both one-click locks while gently removing the top panel.



2. Install the HDD


Remove the HDD cage panel, take out the cage, install the hard drives, and securely reinstall the cage.

2




3. Install the Motherboard

3



4. Install the PSU

4



SPECIFICATIONS

Model	
Model Name	RSV-Z2008
Specifications	
Chassis Type	Rackmount
Form Factor	2U
Color	Silver & Black
Case Material	SGCC
Motherboard Compatibility	12" x 9.6" ATX, 11.2" x 8.2" Mini-ATX and below
Power Supply	2U / CRPS
Hot-Swap Drive Bays	-
External 3.5 Drive Bays	2
Internal 3.5" Drive Bays	6
Internal 2.5" Drive Bays	-
Expansion Slots	7
Front USB	2 x USB 3.0 / 1 x USB 3.2 Type C
80mm Fans	Middle: 3 x 80mm fans (3 x 8038 PWM fan included)
120mm Fans	-
Physical Specification	550 x 430 x 89 mm / 21.65" x 16.93" x 3.50"

Rosewill®

Technical Support Information techsupport @ rosewill.com 1-800-575-9885

Please register your product at www.rosewill.com for complete warranty information and support for your product.



RSV-Z2008