



PRODUCT OVERVIEW


Product Diagram



Dimensions (W x H x D): 650 x 431 x 177 mm (25.59" x 16.97" x 6.97")



Accessory Kit




INSTALLATION GUIDE

Please remove all packaging materials before proceeding to disassembly/assembly.

1. Remove the Top Panel



Loosen the two screws on the side panel, then press and hold both one-click locks while gently removing the top panel.



2. Install the HDD


Mount the HDD onto the hot-swap tray and reinsert the HDD cage.

2




3. Install the Motherboard

3




4. Install the GPU

4




5. Install the PSU

5



6. Install the Radiator

6



SPECIFICATIONS

Model	
Model Name	RSV-H424
Specifications	
Chassis Type	Rackmount
Form Factor	4U
Color	Silver & Black
Case Material	SGCC
Motherboard Compatibility	12" x 13" E-ATX, 12" x 9.6" ATX, 11.2" x 8.2" Mini-ATX and below
Power Supply	Supports ATX power supply
Hot-Swap Drive Bays	24 (SFF8643 with SGPIO and Temperature Control)
External 3.5 Drive Bays	-
Internal 3.5" Drive Bays	-
Internal 2.5" Drive Bays	-
Expansion Slots	7
Front USB	2 x USB 3.0
80mm Fans	-
120mm Fans	Middle: 3 x 120mm fans (3 x 12038 PWM fan included)
Physical Specification	650 x 431 x 177 mm / 25.59" x 16.97" x 6.97"

Rosewill®

Technical Support Information [techsupport @ rosewill.com](mailto:techsupport@rosewill.com) 1-800-575-9885

Please register your product at www.rosewill.com for complete warranty information and support for your product.



RSV-H424