


Rosewill®



FBM-X6

Quick User Guide




Table of Contents

• Product Overview	
Disassembly Chart	2
Accessory Box	3
• Installation Guide	
1. Open the Unit	4
2. Install Motherboard	5
3. Install Add-on Card	5
4. Install 3.5" /2.5" HDD/SSD	6
5. Care	7
6. Options	8
• Specifications Table	9
Front I/O Cable Pinout	10
Front I/O	10


Thank you for purchasing a **Rosewill** Computer Case.
Please read the instruction manual before use and
retain for future reference.

Product Overview

Disassembly Chart (components vary by country)



Dimensions: 210*400*450mm (W x D x H)



Accessory Box


Image	Part Name	Qty	Function/Component
	PSU screws	8	PSU Add-on Card
	Motherboard screws	14	Motherboard 2.5" HDD/SSD
	HDD screws	8	HDD
	Standoff	3	Motherboard
	Installation screws	2	HDD
	Nut Setter	1	Standoff tool
	Cable ties	5	Cable Management
	Name Plate	1	Logo

Installation Guide


1. Open the Unit

1-1. Open and take off left TG side panel and right side panel(Figure 1).

1a




1b




2. Install Motherboard

2-1. Secure the motherboard down with Screw-B(Figure 2)



3. Install Add-on Card


3-1. Remove the slot cover, then install the GPU card and secure with Screw-A(Figure 3)



4. Install 3.5" /2.5" HDD/SSD


4-1.Take off the SSD trays, install SSD onto the trays with Screw B.

4a



4-2.Take off the HDD tray, install HDD onto the tray with Screw C.

4b




5.Care

To prevent damage, keep all panels closed and secured.

5-1. Put the side panels back in place and secure with thumb screws.


5-2. Clean the dust filters on the top and bottom regularly to ensure adequate airflow(Figure 5)



6. Options

6-1. Liquid cooling radiator installation


The FBM-X6 supports 240mm radiator in the front and top for more effectively cool high-performance systems.




Specifications Table

Model	
Model Name	FBM-X6
Specifications	
Type	Mid Tower
Color	Black
Case Material	Steel / Plastic/Tempered Glass
With Power Supply	No
Motherboard Compatibility	M-ATX ITX
With Side Panel Window	No
Expansion	
Internal 3.5" Drive Bays	2
Internal 2.5" Drive Bays	1
Expansion Slots	5
I/O Ports	
Top Ports	2 x USB 3.0 1 x USB 2.0 HD-Audio
Cooling System Options	
120 mm Fans	3 x Front (Included) 2 x Top 1 x Rear (Included)
140 mm Fans	2 x Front 2 x Top
Radiator	Front:240mm Top:240mm

Front I/O Cable Pinout



Front I/O





Rosewill® Technical Support Information
techsupport@rosewill.com 1-800-575-9885

*Thank you for purchasing a quality Rosewill product.
Please register your product at www.rosewill.com
for complete warranty information and support for your product.*