


Rosewill®



FBM-Z1

Quick User Guide




Table of Contents

• Product Overview	
Disassembly Chart	2
Accessory Box	3
• Installation Guide	
1. Open the Unit	4
2. Install Motherboard	5
3. Install Add-on Card	5
4. Install 3.5" /2.5" HDD/SSD	6
5. Install Power Supply.....	6
• Specifications Table	7
Front I/O Cable Pinout	8
Front I/O	8



Thank you for purchasing a **Rosewill** Computer Case.
Please read the instruction manual before use and
retain for future reference.

Product Overview

Disassembly Chart (components vary by country)



Dimensions: 220*435*356mm (W x D x H)





Accessory Box

Image	Part Name	Qty	Function/Component
	Screw-A (HWM6*5)	10	PSUAdd-on Card
	Screw-B (PWM3*5*7)	14	Motherboard /SSD
	Screw-C (BM6*5)	8	PSU
	Screw-D	4	SSD
	SSD Spacer	4	SSD
	Screw-E	4	HDD
	HDD Spacer	4	HDD
	Standoff	2	Motherboard
	Cable Tie	5	Cable Management
	Name Plate	1	Logo

Installation Guide


1. Open the Unit

1-1. Open and take off Left and right side panel(Figure 1).




2. Install Motherboard

2-1. Secure the motherboard down with Screw-B(Figure 2)




3. Install GPU-card

3-1. Remove the slot cover, then install the GPU card and secure with Screw-A(Figure 3)




4. Install 3.5" /2.5" HDD/SSD

4-1.Take off the HDD trays, install SSD/HDD onto the tray with Screw B/Screw C.



5. Install Power Supply


5-1: Take off the PSU plate and screw on PSU on the top of the case with Screw A(Figure 5)




Specifications Table

Model	
Model Name	FBM-Z1
Specifications	
Type	Mid Tower
Color	Black
Case Material	Steel / Plastic
With Power Supply	Yes
Motherboard Compatibility	Micro-ATX ITX
With Side Panel Window	Yes
Expansion	
Internal 3.5" Drive Bays	1
Internal 2.5" Drive Bays	3
Expansion Slots	5
I/O Ports	
Top Ports	1 x USB3.0 1 x TYPE-C HD Audio
Cooling System Options	
120 mm Fans	3 x Top 1 x Rear (Included) 2 x Bottom

Front I/O Cable Pinout



Front I/O





Rosewill® Technical Support Information
techsupport@rosewill.com 1-800-575-9885

*Thank you for purchasing a quality Rosewill product.
Please register your product at www.rosewill.com
for complete warranty information and support for your product.*